

Powerdot MIDI

ERGO-SL008M

A - Removable installation

B - Permanent installation

CONTENT:



x1



x1



x2




- 1 Lid type cable-through

- 1 Schuko socket

- 1.5 meter cable

1A DRILL
Drill a hole in the table



Ø60 mm

REMOVABLE
INSTALLATION


1B DRILL
Drill a hole in the table



Ø60 mm


PERMANENT
INSTALLATION

2A INSERT
Insert Powerdot into the hole and feed the power plug through the plastic fastening nut (without using the cable clips).




REMOVABLE
INSTALLATION

3A TURN CLOCKWISE & PLUG IN
Turn the plastic fastening nut as far up the thread as possible. Make sure it has been thoroughly tightened. Lastly, plug it in to the wall socket.



Max 52 mm

2B ATTACH & INSERT (NON REMOVABLE)
Attach clips by guiding them into the side tracks. The clips will keep the product in place without the fastening nut. Push the Powerdot all the way down the hole. Lastly, plug it in to the wall socket.



PERMANENT
INSTALLATION

Minimum
20 mm

HOW TO REMOVE (WITH CLIPS)
To increase your chances of removing once installed with clips, turn the grommet clockwise. Until the clips re-position and loosen up.

NOTE! The table or product might get damaged during the process.



PULL UPWARDS
If you successfully loosened up the clips. Pull upwards until fully removed.

