

Vertical Mouse




User Manual

Thank you for choosing this special wired vertical mouse. Please read the user manual carefully when using this product.

►Contents:

- Wired vertical mouse ---- x 1
- User manual ----- x 1
- CD driver (Optional) ----- x 1

►Button Function:



►Features

- Vertical mouse, worm bionic shape design
- Floating RGB light effect, provides with different experience
- Ergonomic design with the removable palm rest, to reduce the hand and wrist pain

➤ Installation

Plug the USB connector for the wired mouse to USB port in your computer, after detecting successfully it will work normally.

➤ Specification

Solution	PAN3212
Version	Wired
Light Mode	Floating RGB. ON/OFF switch is on the is on the bottom.
DPI	800/1200/1600/2400/4000 DPI, DPI cycle is on the bottom of the mouse
Polling Rate	500Hz
Working Voltage	5V
Working Current	≤70mA

➤ Driver Installation

Install the driver from the CD in the package, or you can download it from: <http://www.deluxworld.com>

Tip:

Please make sure the mouse has already been connected to your computer when installing the driver.

➤ Driver Setting Instruction

After installation ok, get into the setting interface, you can start to set up the mouse function





➤ Driver Setting Instruction

After installation ok, get into the setting interface, you can start to set up the mouse function.

A. Button Setting (Custom)

7 buttons can be set the function (G1~G7).10 functions can be chosen for one button. Refer to picture A.

For Mouse function mode, 11 different functions you can choose. Refer to picture B.




On several modes, you can adjust the light brightness and speed.

Note:

The function of Left Click cannot be set firstly, only after other button to be set as the function of Left Click.


B. Performance

By adjusting the coordinate, you can set the Sensitivity (DPI), Pointer Speed and Polling Rate.



C. Light

You can set different light mode: All off, Full-lighted, Breathing, Floating RGB mode, Running RGB mode, Neon RGB mode.



➤ Macro

Assign a Macro:

- 1) Open Macro on the main interface.
- 2) Choose one existed macro to modify it, or add to create a new one.
- 3) Click "Record" to start the recording, and click "Stop" to finish it.
- 4) You can set the default delay or no delay by choosing Record delay.

